FLUSH HANDLE CONTROL **FOR ATLANTES**

Installation and Maintenance Instructions

THE FOLLOWING ARE CAUTIONARY STATEMENTS THAT MUST BE READ AND FOLLOWED DURING BOTH INSTALLATION AND OPERATION.

WARNING: Raritan Engineering Company, Inc. recommends that a qualified person or electrician install

> this product. Equipment damage, injury to personnel or death could result from improper installation. Raritan Engineering Company, Inc. accepts no responsibility or liability for damage to equipment, injury or death to personnel that may result from improper installation


or operation of this product.

WARNING: HAZARD OF SHOCK OR FIRE

Always use recommended fuse, circuit breaker and wire size.

DO NOT install in the area requiring "Ignition protected" devices.

FLUSH LEVER POSITIONS



Pull Handle

Description:

"02" model:

The 02 model is designed to work as a momentary unit using only microswitches to activate the motors. It is also a "fail safe" mode for the toilet control in the 03 model.

"03" model:

The "03" model contains an smart toilet control which provides timed operation while still having momentary functionality if toilet control is removed.

Operation:

Pull Handle Forward:

Model 03 - Pull handle forward and release: starts a timed flush, intake pump starts followed by discharge pump.

Model 02 - Pull handle forward and hold to add water.

Push Handle Backward:

In both models runs just the discharge pump for a "dry bowl" flush.

Push Handle





NOTES: for Wiring

1.	Distances are from source to unit and back to source.
2.	Distance from power source to remote intake pump MUST be included when determining total distance.Same wire size MUST be used for lower base and remote intake pump.
3.	Recommended conductor wire minimum AWG (mm²) for 3% voltage drop.
4.	Recommended conductor sizes are based on 105°C rated insulation.

For 120/240 VAC units use 12VDC specifications from transformer to unit.

CONVERSIONS Wire - AWG to mm ²													
AWG	16	14	12		10		8		6		4	2	
mm²	1.5	2.5	4.	4.0 6)	10.0		16.0		25.0	35.0	
		F	е	et t	o I	Иe	ter	s					
Feet	10	15		20		25		30		40		50	
Meter	3.1	4.6		6.1		7.6		9.2		2 12.2		15.2	


Sea Water Model - Recommended Wire and Fuse/Circuit Breaker Size

Units Voltage	Circuit Breaker/fuse size (amps)	Discharge Amp. draw	Remote Pump Only Amp. draw	15 feet	20 feet	30 feet	40 feet	50 feet
12 VDC	30	18	10	10 AWG	8 AWG	6 AWG	6 AWG	4 AWG
24 VDC	20	10	5	14 AWG	14 AWG	12 AWG	10 AWG	10 AWG

Pressurized Freshwater Model - Recommended Wire and Fuse/Circuit Breaker Size

Units Voltage	Circuit Breaker/fuse size (amps)	Amp. draw	10 feet	15 feet	20 feet	30 feet	40 feet	50 feet
12 VDC	25	18	12 AWG	10 AWG	10 AWG	8 AWG	6 AWG	6 AWG
24 VDC	15	10	14 AWG	12 AWG	10 AWG	10 AWG	8 AWG	6 AWG

Fig. 1 WIRING FOR MOMENTARY FLUSH HANDLE CONTROL, FRESHWATER MODEL



WIRING

WARNING: Hazard of Shock and Fire

- Always use proper wire, wire connectors and fuse/circuit breaker. See Specification Chart.
- Secure wire properly.
- Do not connect appliances to toilet circuit.
- Make sure power is off before proceeding.
- 1. Determine proper wire size by measuring distance from:
 - Power Source to push button to toilet motor and back to power source.
 - Remote pump units also include distance from power source for remote pump to remote pump and back. Same wire gauge must be used for both discharge and remote pump.
- 2. Select proper wire and fuse/circuit breaker size from Specifications on specification page.
- 3. Install fuse/circuit breaker in positive line at source.
- 4. Wire control to the toilet and battery using one of the following wiring diagrams.

Mounting control:


Mounting control box:


- 1. Locate a place for control box near toilet. Do not install box more than six feet away to avoid excessive volatage drop
- 2. Route wires between toilet and control, Cut all extra lengh of wires to keep voltage drop to minimum


MARINE SANITATION DEVICE OPERATION

To start Electroscan from toilet control, run a wire from "to MSD" to terminal marked "EXT TRIG" inside Electroscan control module (black box). To start toilet equipped with Smart toilet control from Electroscan, connect "Head1" to "FROM MSD".

For Lectra/San MC, EC call Raritan Customer Service or visit www.raritaneng.com







For limited warranty terms and conditions please refer to toilet manual



530 Orange Street, Millville, NJ 08332 USA

Telephone: 856-825-4900 FAX: 856-825-4409

www.raritaneng.com
Southern Office and Plant:

3101 SW Second Avenue, Fort Lauderdale, FL 33315 USA

Telephone: 954-525-0378 FAX: 954-764-4370